



Maintenance instructions: Eden Wood's pine wood furniture

- All wood used outdoors must be protected from cracks, wet weather and from drying out. We recommend you to use Chinese wood oil within one month after you bought the furniture. It is important to wipe off superfluous wood oil immediately. Repeat this treatment regularly once every year or more, depending on usage.
- Wash your furniture regularly with mild soap-water in order to prevent dirt and micro-organisms from developing into mould fungus. Should black spots occur, wash the furniture first with wood cleaner and then Chinese wood oil.
- For all treatment of the surface it is important that the furniture is clean and dry and that you follow the instruction from your colour supplier.
- Resin can appear - especially at high temperatures. The resin can be removed with methykated spirit or white spirit. When the resin has dried, it can be scraped off carefully with a knife, without damaging the surface.
- Before autumn and winter the furniture should be washed and kept under shelter.
- For the best comfort and functioning, all screws should be tightening during the season.